

5. Attach both left and right armrests (C) to seat cushion (B) and back cushion (A) by using the screws for armrest (E1).
6. Insert the pre-assembled seat unit onto the gas lift.
7. Finish the assembly.
8. Tighten all bolts firmly after assembly is complete.
9. Lubricate all moving parts and tighten all bolts every 6 months.

PARTS LIST:

| | |
|-------------------------------------|-------|
| A. BACK CUSHION..... | 1 PC |
| B. SEAT CUSHION | 1 PC |
| C. ARM REST (LEFT & RIGHT)..... | 1 PR |
| D. MECHANISM | 1 PC |
| E. SCREWS FOR MECHANISM(M8*25)..... | 4 PCS |
| E1. SCREWS FOR ARMREST(M8*25)..... | 8 PCS |
| F. 3-TIER COVER | 1 PC |
| G. GAS LIFT..... | 1 PC |
| H. NYLON BASE..... | 1 PC |
| I. CASTERS..... | 5 PCS |

Assembly Instruction

Carefully unpack all parts and identify them with parts list before attempting to assemble:

1. Insert the 5 casters (I) into the holes on the aluminum base (H).
2. Insert the gas lift (G) to the center hole on top of the Nylon base (H).
3. Insert the 3-tier cover (F) over the gas lift (G).
4. Fasten the mechanism (D) onto the seat cushion (B) by using the screws for mechanism (E)

VL601XX