



ESP

STANDARD SHELVING PACKAGE

12" 15" 18" 24"

PACKING LIST

4	Corner Post
5 or 6	Shelves
4	Side Sway Plates
1	Pair Back Braces
20	1/4 - 20 x 5/8 Bolts
20	1/4 - 20 Nuts
20	Standard Shelving Clips

ASSEMBLY INSTRUCTIONS

1. Lay two corner posts parrallel on saw horses with short side facing up.
2. Bolt a sway plate approximately 10" from the top and another 10" from the bottom of the post.
3. Place shelf clips in top and bottom holes of each post.
4. Repeat steps 1 through 3.
5. Lean one side assembly against wall or other upright surface and place shelf on bottom clips.
6. Place second end assembly in place and hook bottom shelf in over clips.
7. Place top shelf over the four (4) clips at top of post.
8. Bolt rear sway braces in place. The top of the brace should be in the 27th hole from top of post. Be sure they are stretched to full extension, otherwise the braces will appear floppy.
9. Position remaining shelves in place with clips.

ESP STANDARD SINGLE UNIT ASSEMBLY

