



PRESTIGE[®] WHITEBOARD ERASER

Directions for use:

1. Use Prestige Eraser on all marker board surfaces.
2. When felt sheet becomes dirty, remove and discard bottom layer and continue using.
3. To refill eraser peel away paper backing from refill pads, align with Prestige Eraser base, and press firmly into place.

 ACCO Brands (Returns Center)
101 Bolton Ave 9E
Booneville, MS 38829 USA
Tel: 800-541-0094
www.acco.com
www.quartet.com

Quartet is a registered trademark of General Binding Corporation. ACCO name and design is a registered trademark of ACCO Brands. © 2013 ACCO Brands Corporation. All Rights Reserved.

Quartet est une marque déposée de General Binding Corporation. Le nom ACCO et son dessin est une marque déposée d'ACCO Brands. © 2013 ACCO Brands Corporation. Tous droits réservés.

Quartet es una marca registrada de General Binding Corporation. El nombre y el diseño de ACCO son marca registrada de ACCO Brands. © 2013 ACCO Brands Corporation. Todos los derechos reservados.