

WOOD SLAB BASE

INSTALLATION INSTRUCTIONS

Illustration 1




Illustration 2





Illustration 3



Read all instructions and review illustrations before installing.

Tools required for assembly
Phillips screwdriver Rubber mallet

This assembly includes:

- (1) Table top
- (2) Slab base panel
- (4) Dowel
- (4) Cam bolt
- (4) Cam connector
- (2) Stretcher bracket
- (16) $\frac{3}{8}$ " long screw
- (8) $3\frac{1}{2}$ " long screw
- (4) Glide

⚠ WARNING

Wood products are heavier than they appear and may be hard to control when moving. Use two or more people when moving wood products or severe personal injury may result.

Heavy panels can pinch or crush fingers. Do not place fingers between or under panels during assembly.


Installation:

1. Refer to Illustration 1. Lay table top upside down on cardboard or a carpeted surface. Use the Phillips screwdriver to install four cam bolts (from hardware pack) into locations shown. Tighten cam bolts until cam bolt shoulder is flush against bottom surface of table top.

Use the rubber mallet to install four wood dowels (from hardware pack) into top at locations shown.
2. Refer to Illustration 2. Use the Phillips screwdriver to install four $3\frac{1}{2}$ " long screws (from hardware pack) through each stretcher bracket and into pre-drilled holes in bottom of table top. Do not fully tighten screws.
3. Refer to Illustration 3. With holes facing center of table top, position slab base panels onto cam bolts (attached to table top). Insert cam bolts into holes along top edge of each slab base panel.


WOOD SLAB BASE

Illustration 4




4. Refer to Illustration 4. With arrows facing the bottom of table top, install two cam connectors (from hardware pack) into holes along edge of each slab base panel. Use the Phillips screwdriver to tighten cam connectors. Turn cam connectors approximately $\frac{1}{2}$ turn clockwise to tighten.

Illustration 5



5. Refer to Illustration 5. Use the Phillips screwdriver to install four $\frac{3}{8}$ " long screws (from hardware pack) through each stretcher bracket mounting plate and into slab base panels. Fully tighten all screws.

Illustration 6



6. Refer to Illustration 6. Locate threaded inserts on bottom edge of upper and lower base panels. Thread four glides (from hardware pack) into threaded insert by turning glides clockwise until glides are flat against base panels.
7. After leveling glides are fully installed, use two or more people to set table upright and position table where it will be used.
8. Adjust glides until table is level.